

# F-3212 Installation Instructions

Read Entire Instructions Sheet Before Beginning

Safety Glasses	Assortments Wrench
Window Cleaner and Paper Towels	Phillips Head Screwdriver
Gloves	Clear silicone

## Steps:

1) Remove your current visor if you have one:

A) Note: You will need to reuse the bolts which go into the side of the cab at the ends of the visor.

2) Install the mounting bracket per side. Remove the lights and install on the visor. Make sure to disconnect the light cables and not cut.

A) Fill wire holes with silicone, under the new bracket and in the threading for the screws, to mounting brackets.

3) Tighten the brackets to the cab and clean off any extra silicone

4) Remove the PVC coating from the visor.

A) Note: Remove PVC from around the holes for the brackets and not the whole visor. Helps with scratching and less to clean.

5) Place the visor brackets on the cab brackets. Finger tight

6) Install the driver's side portion of the visor first.

A) Finger-tighten the "side of cab bolts" of the visor.

B) Start the machine screws into the outside bracket to temporarily hold it in position.

7) Repeat Step 6 with the passenger side.

8) Where the visors join together, screw in the top and bottom machine screws until finger tight. You might have to remove the screws from the outside brackets to have the center holes line up. The visor is made to fit very snug, and you might need to place a small screwdriver in the middle to help align the middle holes.

9) Align the visor by snugly tightening one of the screws in each mounting bracket. Start from the outside of the cab and work toward the middle, one screw per bracket at a time.

10) Once the visor is in alignment, tighten the screws with the washers and nylon lock nuts.

11) Tighten all remaining bolts and machine screws.

12) Wipe away fingerprints using window cleaner and paper towels.