



**NOTE 2**

INSTALLATION INSTRUCTIONS

- 1- REMOVE GRILL
- 2- PLACE THE HOOD DEFLECTOR, MAKING SURE IT IS CENTERED ON THE HOOD AND LEANING ON GRILL INDENT. **NOTE 2**
- 3- MARK THE TABS AND SIDES HOLES ON THE HOOD.

**CAUTION**  
**BEFORE DRILLING,**  
**REMOVE THE HOOD DEFLECTOR**  
**TO PREVENT DAMAGE**

- 4- DRILL THE TABS HOLES AS MARKED AT 7/32"DIA. (.21875")
- 5- DRILL BOTH SIDES HOLES MARKED AT 9/32" DIA. (.28125")
- 6- INSTALL THE HOOD DEFLECTOR AS ILLUSTRATED.
- 7- TEMPORARILY ATTACH THE HANDLE TO THE HOOD DEFLECTOR WITH HARDWARE AS ILLUSTRATED.
- 8- MARK THE HANDLE HOLES ON THE HOOD.

**CAUTION**  
**BEFORE DRILLING,**  
**REMOVE THE HOOD DEFLECTOR HANDLE**  
**TO PREVENT DAMAGE**

- 9- DRILL THE HANDLE HOLES AS MARKED AT 9/32" DIA. (.28125")
- 10- FASTEN THE HOOD DEFLECTOR HANDLE ONTO THE HOOD AS ILLUSTRATED.
- 11- TIGHTEN ALL BOLTS AND SCREWS.
- 12- REINSTALL GRILL.

\* NUMBER ON PARTS MAY BEGIN WITH «CL» INSTEAD OF «PR»

ITEM No.	PART NUMBER	DESCRIPTION	QTY
1	M7321005SC	HOOD DEFLECTOR	1
2	K7321005BH	HARDWARE KIT INCLUDES:	-
3	-	CL9321005-C01	1
4	-	WELL NUT 1/4"-20NC	2
5	-	TRUSS PHILIPS #10-32NFX1"SS	4
6	-	TRUSS PHILLIPS #10-32NF X 1/2"SS	2
7	-	TRUSS PHILIPS 1/4-20NCX1"SS	2
8	-	FLAT WASHER 1/4" SS	2
9	-	FLAT WASHER ID#10 X OD 1/2" SS	6
10	-	NYLON LOCK NUT #10-32NF SS	6
11	-	FENDER WASHER 1/4"ODT 1/4"SS	2
12	-	LOCK WASHER 1/4" SS	2
13	-	HEX NUT 1/4-20NC	2
14	-	TRUSS PHILIPS 1/4"-20NCX3/4"SS	2

**TRUX ACCESSORIES**

TITLE:  
 HOOD DEFLECTOR  
 FREIGHTLINER - COLUMBIA 2001 & UP

SIZE: DWG. NO.  
**ATHOD-FLCOL**

NAME	DATE	REV	DATE
P.W.	16-10-2008	PH2	-

SCALE: 1:9      WEIGHT: LBS      SHEET: 1 OF 1