

No. ARTICLE	PART NO.	DESCRIPTION	QTY
1	M7331014SG	SUNVISOR	1
2	M7331014SD	SUN VISOR	1
3	K7331014BH	HARDWARE KIT INCLUDES:	1
4	-	PR9331014-G00	2
5	-	PR9331014-D00	2
6	-	PR9331014-C00	1
7	-	FLAT WASHER 1/4" SS	20
8	-	TRUSS PHILIPS 1/4"-20NCX3/4"SS	20
9	-	LOCK WASHER 1/4" SS	20
10	-	HEX NUT 1/4-20NC	16
11	-	LF,INSERT STL 1/4"-20NC X.160	4

**TRUX ACCESSORIES**

TITLE: SUN VISOR  
 FREIGHTLINER BUSINESS CLASS M2 06&UP,  
 108 SD, 114SD 12&UP

SIZE DWG. NO.  
**A TSUN-F28**

NAME	DATE	REV	DATE
DRAWN BY P.W.	-	PH1	-

SCALE: 1:8      WEIGHT: LBS      SHEET: 1 OF 1

## BEFORE BEGINNING INSTALLATION, READ ALL INSTRUCTIONS


### INSTALLATION INSTRUCTIONS

- 1- REMOVE THE EXISTING SUN VISOR AND RETAIN HARDWARE.
- 2- INSTALL THE BRACKETS ONTO THE CAB WITH THE RETAINED HARDWARE, DO NOT TIGHTEN.
- 3- TEMPORARILY INSTALL THE SUN VISOR AS ILLUSTRATED.
- 4- AT BOTH ENDS REMOVE DOOR GASCKETS AND PUSH THE SUN VISOR IN PLACE AND MARK HOLES IN DOOR FRAME.

### CAUTION

#### REMOVE SUN VISOR TO PREVENT DAMAGE

- 6- DRILL THE PREVIOUSLY MARKED OUT HOLES AT 25/64" (.390625")IN. DIA.
- 7- INSERT THE THREADED INSERT.
- 8- REINSTALL THE SUN VISOR ON THE CAB.
- 9- TIGHTEN ALL BOLTS AND SCREWS FIRMLY.



TRUX ACCESSORIES			
TITLE: SUN VISOR FREIGHTLINER BUSINESS CLASS M2 06&UP, 108 SD, 114SD 12&UP			
SIZE	DWG. NO.		
<b>A</b>	<b>TSUN-F28</b>		
NAME	DATE	REV	DATE
DRAWN BY P.W.	-	PH1	-
SCALE: 1:8	WEIGHT: LBS	SHEET: 1 OF 1	