

ITEM NO.	PART NO.	DESCRIPTION	QTY
1	M7231012SD	SUN VISOR PANEL	1
2	M7231012SG	SUN VISOR PANEL	1
3	K7231012BH	HARDWARE KIT INCLUDES:	6
4	-	PR9231012-C01	1
5	-	PR9231012-D02	1
6	-	PR9231012-D01	1
7	-	PR9231012-G01	1
8	-	PR9231012-G02	1
9	-	PR7231012	3
11	-	TRUSS PHILIPS 1/4"-20NCX3/4"SS	17
12	-	HEX. BOLT 1/4NC X 1	10
13	-	LOCK WASHER 1/4" SS	29
14	-	FLAT WASHER 1/4" SS	23
15	-	TRUSS PHILIPS 1/4"-20NCX1"SS	2
16	-	HEX NUT 1/4"-20NC	17
17	-	LF.INSERT STL 1/4"-20NC X.160	4
18	-	WELL NUT 1/4"-20NC	2

TRUX ACCESSORIES

TITLE:
**SUN VISOR KENWORTH CURVED GLASS
 GANGSTER SERIE ALL MODELS 2007 & UP**

SIZE DWG. NO.
A TSUN-K5

NAME	DATE	REV	DATE
DRAWN BY P.W.	16-01-2008	PH1	-

SCALE: 1:10 WEIGHT: LBS SHEET: 1 OF 1

READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION


INSTALLATION INSTRUCTIONS

- 1- REMOVE THE EXISTING SUN VISOR AND RETAIN HARDWARE.
- 2- INSTALL THE BRACKETS ONTO THE EXISTING HOLES WITH RETAINED HARDWARE.
- 3- TEMPORARILY INSTALL THE SUN VISOR AS ILLUSTRATED
- 4- USING THE SUN VISOR, MARK HOLES ON BOTH ENDS OF SUN VISOR.

ATTENTION

REMOVE SUN VISOR BEFORE DRILLING TO PREVENT DAMAGE

- 5- DRILL THE PREVIOUSLY MARKED OUT HOLES AT ½" (.5") DIA.
- 6- INSERT THE WELLNUTS.
- 7- REINSTALL THE SUN VISOR ON THE CAB.
- 8- TIGHTEN ALL BOLTS AND SCREWS FIRMLY.



TRUX ACCESSORIES			
TITLE: SUN VISOR KENWORTH CURVED GLASS GANGSTER SERIE ALL MODELS 2007 & UP			
SIZE	DWG. NO.		
A	TSUN-K5		
NAME	DATE	REV	DATE
DRAWN BY P.W.	16-01-2008	PH1	-
SCALE: 1:24	WEIGHT: LBS	SHEET: 1 OF 1	