


ITEM NO.	PART NO.	PART NO.	PART NO.	DESCRIPTION	QTY
1	M7231004SG	M7231005SG	M7231006SG	SUN VISOR PANEL	1
2	M7231004SD	M7231005SD	M7231006SD	SUN VISOR PANEL	1
3	K7231004BH	-	-	HARDWARE KIT INCLUDES :	1
4	-	-	-	PR9231004-D00	1
5	-	-	-	PR9231004-G00	1
6	-	-	-	PR9231004-C00	1
7	-	-	-	FLAT WASHER 1/4" SS	22
8	-	-	-	WELL NUT 1/4"-20NC	6
9	-	-	-	TRUSS PHILIPS 1/4"-20NCX3/4"SS	16
10	-	-	-	HEX. BOLT 1/4"NC X 1	6
11	-	-	-	HEX NUT 1/4"-20NC	16
12	-	-	-	LOCK WASHER 1/4" SS	16

TRUX ACCESSORIES			
TITLE: SUN VISOR KENWORTH W900 & T800 GANGSTER SERIES FLAT GLASS			
SIZE	DWG. NO.		
A	TSUN-K8, TSUN-K10, TSUN-K9		
	NAME	DATE	REV
DRAWN BY	P.W.	29-09-2008	PH1
SCALE: 1:24		WEIGHT: LBS	SHEET: 1 OF 1



FRONT

**READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION**


INSTALLATION INSTRUCTIONS

- 1- REMOVE THE EXISTING SUN VISOR.
- 2- REDRILL EXISTING HOLES TO 1/2 in. AND INSERT WELLNUTS.
- 3- INSTALL THE BRACKETS ONTO THE CAB.
- 4- TEMPORARILY INSTALL THE SUN VISOR AS ILLUSTRATED
- 5- USE RECOVERED HARDWARE FOR HOLES ON BOTH ENDS OF SUN VISOR.
- 6- IF WITHOUT LIGHTS; SKIP TO STEP#10.
- 7- INSTALL THE LIGHTS ON SUN VISOR
- 8- CONNECT THE LIGHTS AND DIRECT WIRE TOWARDS CENTER.
- 9- FASTEN THE SUN VISOR USING THE FASTENING HARDWARE.
- 10- REINSTALL THE SUN VISOR ON THE CAB.

**CAUTION**

**IT IS THE RESPONSIBILITY OF THE INSTALLER TO PLAN AHEAD THE ADEQUATE ELECTRICAL CONNECTION ACCORDING TO THE STANDARDS OF THE TRUCK MANUFACTURER AND DOT REGISTRATION.**

- 11- CONNECT LIGHTS HARNESS TO THE TRUCK.
- 12- TIGHTEN ALL BOLTS AND SCREWS FIRMLY.



BACK

<b>TRUX ACCESSORIES</b>			
TITLE: SUN VISOR KENWORTH W900 & T800 GANGSTER SERIES FLAT GLASS			
SIZE <b>A</b>	DWG. NO. <b>TSUN-K8, TSUN-K10, TSUN-K9</b>		
NAME	DATE	REV	DATE
DRAWN BY P.W.	29-09-2008	<b>PH1</b>	-
SCALE: 1:24		WEIGHT: LBS	SHEET: 1 OF 1