

**Window Guard Instructions for Dual Window 2005 to Current Cascadia Day Cab Trucks**

**BEFORE INSTALLATION**

**Inspection:** Before installation, inspect all parts for shipping damage. If any of the parts appear damaged or questionable, DO NOT INSTALL! Contact your dealer or our facility for a replacement part or assistance. Once a product is installed, it cannot be returned because of shipping damage.

**Important:** Read and understand all installation instructions prior to installation. If any part of the instruction seems unclear, contact our office for assistance. (Monday – Friday 8am to 4:30pm CST at 800-982-1180 or 847-662-7722)




**VIDEO WALKTHROUGH**

For a fully voiced video walkthrough of the installation, scan the QR code.



**DIGITAL INSTRUCTIONS**

For a digital version of the instructions to be able to zoom in on photos, scan the QR code.



**TOOLS NEEDED**

- #3 Phillips Screwdriver, 7/16" wrench, 7/16" Socket, Drill, 7/16" Drill Bit, Marker, Level
- (Optional): Center Punch, Hammer, 1/8" Drill Bit

**Scan QR Codes at the top of this page for full color instructions and installation video.**

**STEP 1: MARKING LOCATION FOR MOUNTING**

Begin by aligning the supplied templet on the upper outside corner of the window (See Fig. 1). Mark the body of the truck through the slot on the templet (Fig. 2 & 3). Because the window location varies slightly from truck to truck, you will need to make a vertical line that intersects with the horizontal line approximately in the center of the mounting surface (Fig. 4).




**FIGURE 1**



**FIGURE 2**



**FIGURE 3**



**FIGURE 4**

**STEP 2: DRILLING HOLE ON YOUR MARK**

Now you will need to drill a 7/16" hole on your mark. We prefer to first center punch the location (See Fig. 5), and then drill a 1/8" starter hole (Fig. 6). This will make it much easier to drill your full size 7/16" hole (Fig. 7).




FIGURE 5



FIGURE 6



FIGURE 7

**STEP 3: INSTALLING JACK NUT AND SCREW**

Insert a jack nut into the hole (See Fig. 8) and take the supplied flat washer and oversized nut and slide them onto the 1/4-20 x 1 1/2" hex bolt and thread it fully into the jack nut finger tight (Fig. 9). Now, using a 7/16" wrench hold the nut secure while you tighten the bolt with a 7/16" socket to 6 ft-fb (72 in-lb) (Fig. 10). Now you can partially insert a supplied 1/4-20 x 3/4" Phillips screws (Fig. 11).



FIGURE 8



FIGURE 9




FIGURE 10



FIGURE 11

**STEP 4: MARKING OTHER MOUNTING LOCATIONS**

Hang the window guard off of the one bolt (See Fig. 12) and place a level across the top of the window guard (Fig. 13). Mark the other 3 mounting locations (Fig. 14). Repeat Steps 2 and 3 for the other three mounting locations.




FIGURE 12




FIGURE 13



FIGURE 14

**STEP 5: MOUNTING THE WINDOW GUARD**

Place a second screw in the other upper jacknut and hang the window guard (See Fig. 15). Insert the bottom 2 screws (Fig. 16) and fully tighten all 4 screws. We like to space the support brackets evenly across the top and bottom of the window guard, but you can adjust them to fit around other existing brackets and handles. Take a supplied support bracket and place it behind the window guard (Fig. 17). Using another Phillips head screw, mount the support in the mounting slots of the window guard (Fig. 18) and repeat for the other 3 support brackets.




FIGURE 15




FIGURE 16



FIGURE 17




FIGURE 18

**STEP 5: MOUNTING THE WINDOW GUARD (CONTINUED)**

The window guard is now installed (See Fig. 19). Now remove the protective pvc film from the window guard (Fig. 20). Repeat this process for the other window and you are all finished, great job on installing your new RealWheels Window Guards! (Fig. 21)




FIGURE 19




FIGURE 20



FIGURE 21

**RealWheels Corporation • 3905 Route 173 • Zion, IL 60099**

**847-662-7722 • Fax 847-662-7744 • [www.realwheels.com](http://www.realwheels.com) • [info@realwheels.com](mailto:info@realwheels.com) • toll-free 1-800-982-1180**